

Thank you for Purchasing a FAR Mudding Rear Rack

You will be reusing the rear mounts on your existing factory rack to attach the new rack. The holes on the mount will need to be drilled out using a 3/8 drill bit while test-fitting the bolt. If they are too snug we suggest using a 1/2 drill bit. When you take off each OEM mount make sure you put it on the back of the new rack the same way. Switching the mounts side to side will cause them not to line up. **Image below.**

(If you ordered a dry box)

The four strips of 3MVelcro are used for the pelican box. In order for the 3MVelcro to stick we highly recommend using rubbing alcohol to prep the area. Place two strips on the bottom side of the dry box and the other 2 strips on the inside of the black box that you have installed on the machine.

