

## RENEGADE RACK

Thank you for Purchasing a FAR Mudding rear Rack.

-Please take note you will be reusing some of your existing hardware-

You will remove the four torque bolts from your Renegade's rear plastic and then reinstall them with the metal black box provided (double-check to make sure your torque bolts are tightened before you install the rack on top). Once that is installed you will use the three carriage bolts to put the rear rack on.

(If you ordered a dry box)

The four strips of 3M Velcro are used for the pelican box. In order for the 3M Velcro to stick we highly recommend using rubbing alcohol to prep the area. Place two strips on the bottom side of the dry box and the other 2 strips on the inside of the black box that you have installed on the machine.